

Fryer Support Modules



Support modules can include all components necessary for fryer operation.

Reduce installation time of continuous fryer systems 75% or more with no extra costs.

Complete, compact system

This factory assembled module centralizes all fryer support equipment to speed installation, save floor space and simplify maintenance.

Smart design

Designed for your fryer and plant layout, a support module can include the heat exchanger, oil filters, pumps, storage tank, oil cooler and flow control valves, all fully piped and wired to single-point utility connections.

Fast, simple installation

Simply set the support module in place and connect your fryer and utilities. Built by the same experts who manufacture your fryer, the support module eliminates errors and delays caused by inexperienced contractors.

Energy efficient

Located beside your fryer, the support module eliminates the necessity to insulate long piping runs.

Simplify maintenance

Abundant space around the support module provides complete access to all components to facilitate inspection, maintenance and sanitation.

Fryer Support Modules | Model FSM

Customize your support module to fit your fryer and plant layout.

Available in steel or sanitary stainless steel construction, a Fryer Support Module can be equipped with any or all of these components:

- Primary oil filter
- Secondary oil filter
- Main oil circulation pump
- Oil transfer pumps
- Heat exchanger
- Oil storage tank
- Oil cooler
- Oil flow control piping/valves
- Clean-in-place piping/valves
- Compressed air
- Steam train (for steam heat exchanger)
- Piping for fresh oil, used oil, and/or water
- Electrical controls
- Oil collection pan
- Control panel



Cost-effective modules are available for remote-located heat exchangers.

Constant improvement and engineering innovations mean these specifications may change without notice.

HEAT AND CONTROL

®



Headquarters
21121 Cabot Blvd., Hayward, CA 94545 USA
Tel 1 800 227 5980 / 1 510 259 0500 Fax 1 510 259 0600
Campbellville, Canada
Tel 905 854 5650 Fax 905 854 5653
Guadalajara, Mexico
Tel +52 (33) 3689 1146 Fax +52 (33) 3689 2240
Livingston, Scotland
Tel +44 (0)1506 420420 Fax +44 (0)1506 403919
Brisbane, Australia
Tel +61 (0)7 3877 6333 Fax +61 (0)7 3343 8371
Singapore
Tel +65 6273 6362 Fax +65 6273 81610

Over 30 Offices Worldwide www.heatandcontrol.com • info@heatandcontrol.com • ©2007 Heat and Control, Inc.