


HEAT AND CONTROL

®

Pneumatic Salter



1 Distribution cabinet mounts over the fryer discharge conveyor eliminating the hazard of loading salt over moving machinery.

2 Floor level storage/metering cabinet is easy to fill, adjust and clean.

Gentle impingement application provides superior salt adhesion & pack penetration for potato chips & other snacks.

High capacity salting

Ideal for high production rates, the Pneumatic Salter mounts over the fryer discharge or salting conveyor. Salt is gently blown into the chip pack where it bonds to the hot chips with minimal salt waste.

No lumps or clogs

Before it combines with compressed air, salt is sifted by a variable speed metering belt to remove lumps and prevent clogging.

Uniform distribution

Salt is pneumatically transferred to distribution nozzles mounted over the fryer discharge conveyor and evenly blown into the chip pack.

Low level loading

A portable, floor level salt storage and metering cabinet is easy to fill and eliminates the hazard of working over a moving conveyor or hot fryer.

Ready to salt

Pre-wired and plumbed, the Pneumatic Salter is ready to run, complete with a variable speed drive, compressed air regulator and salt distribution tubing.

Easy cleaning




Rugged stainless steel construction features large doors on both cabinets for complete access to the salt storage hopper, metering belt, operating controls and distribution nozzles.

Pneumatic Salter | Model PS

Achieve uniform salting across conveyors up to 60" wide.

Optional equipment

- Free-standing & portable salt distribution cabinets.
- Salter conveyor sections.
- Roll, belt and tumble drum seasoning applicators for operation on processing and packaging lines.



Dimensions are rounded to the nearest inch/centimeter.

Constant improvement and engineering innovations mean these specifications may change without notice.

HEAT AND CONTROL

®



Headquarters
21121 Cabot Blvd., Hayward, CA 94545 USA
Tel 1 800 227 5980 / 1 510 259 0500 Fax 1 510 259 0600

Campbellville, Canada
Tel 905 854 5650 Fax 905 854 5653

Guadalajara, Mexico
Tel +52 (33) 3689 1146 Fax +52 (33) 3689 2240

Livingston, Scotland
Tel +44 (0)1506 420420 Fax +44 (0)1506 403919

Brisbane, Australia
Tel +61 (0)7 3877 6333 Fax +61 (0)7 3343 8371

Singapore
Tel +65 6273 6362 Fax +65 6273 8161

Over 30 Offices Worldwide

www.heatandcontrol.com • info@heatandcontrol.com • ©2005 Heat and Control, Inc.